$High\ Point\ Shoulder\ (HPS)\ is\ measured\ from\ the\ highest\ point\ of\ the\ shoulder\ to\ the\ bottom\ hem\ of\ the\ shirt$

High Point Shoulder Length

Bust/Width

Bust/Width measures across the bust 1" below the armhole, seam to seam.

MENS COTTON LONG BODY CREW

MENS COTTON EGING BODT CHEN							
3602	XS	S	M	L	XL	2XL	3XL
HPS length	29 3/4	30 3/4	31 3/4	32 3/4	33 3/4	34 3/4	35 3/4
Bust 1" below armhole	17 1/2	19	20 1/2	22	24	26	28



